
Setting printers

> In the case of network printing, the program checks every minute if the printer is accessible. If it is not, it will attempt to rediscover it. It is recommended to use a static DHCP server because the connection is based on IP address, which may change if network devices are restarted.

> 3 dot menu -> Settings

Sunmi V2s

Brand: sunmi
Sunmi Label Height: 25
Further settings do not have an impact in this case.




Brother QL-___

WiFi/Ethernet

> Printer setup: books/devices/page/brother-ql-w-series-wifi-setup

Brand: Brother
Interface: Net
Paper Type: W62 (DK-22205)

1. Press "Search and select printers"





Bluetooth


Brand: Brother
Interface: Bluetooth
Paper Type: W62 (DK-22205)


1. Pair the printer via Bluetooth
2. Press "Search and select printers"
3. Enable Bluetooth connection
4. Wait for 1-3 seconds

5. Select the printer


AVAILABLE DEVICES
InnerPrinter
Living Room TV
TelekomTV-STB
Flipper Rio0os
QL-820NWB1748
TelekomTV-STB
Device's Bluetooth address: 74:F7:F6:7A:B4:04
21:58
24%
Bluetooth Printer List


AVAILABLE DEVICES
InnerPrinter
Pair with QL-820NWB1748?
Bluetooth pairing code
644274
Allow access to your contacts and call history
CANCEL
PAIR
Device's Bluetooth address: 74:F7:F6:7A:B4:04
21:58
24%
Settings


Searching for printers:
InnerPrinter
00:11:22:33:44:55
SELECT
QL-820NWB1748
60:77:71:B5:AE:73
SELECT
REFRESH
SETTINGS


Settings
Printer Type
Brand:
brother
Sunmi Label Height:
25
Printer Settings
Interface:
Bluetooth
Paper Type:
W62
Quality:
Normal
Paper Cut Mode:
Always
Secure Height:
True

Revision #1
Created 20 July 2023 19:42:46 by Jozsef Takacs
Updated 20 July 2023 20:03:41 by Jozsef Takacs